


David Begbie a.r.b.s.
289C Rotherhithe Street
Silverhouse
London SE16 5EY
Tel 0044(0)207232 1023
www.davidbegbie.com

Easel Frame Assembly Instructions



To assemble frame, match up the 3 legs to check fit, and slot onto the frame lining up the holes at the back.

Using the Allen Key, counter-turn the screw (already inside the fram) just a few turns in order for it to lock the legs into position. Do not unscrew too much as the small grub screw may come out.

To dismantle, turn the screw into the easel frame, and careful take the legs out one by one being careful when removing not to scratch the legs. For storage or transport, wrap the legs individually